The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.




## Onan

PROTERTY
SERVICE PARTS
LIBRARY
DO NOT REMOVE

# Parts Manual 2.7AJ

R.V. GenSet

O



FORM NUMBER 924-0220



Fich # 202

#### MICROFICHE INDEX #202

#### PARTS CATALOG INDEX FOR 2.7AJ SERJES

#### FICHE LOCATION ILLUSTRATION \*\*\*\* **A3** Data Table A12 \*\*\*\*\*\*\*\*\*\*\* Air Housing Group \*\*\*\*\* Λ9 Carburetor Parts Group A14 \*\*\*\*\*\*\*\*\*\* Control Group \*\*\*\*\*\*\*\*\* Crankshaft, Camshaft & Governor Cup Group A4 \*\*\*\*\* Cylinder Block Group A5 \*\*\*\*\* Exhaust System Group A11 A10 \*\*\*\*\*\*\*\*\*\* Fuel Pump Parts Group \*\*\*\*\* Fuel System Group 8A A7 \*\*\*\*\* Gear Case Group A13 \*\*\*\*\*\*\*\*\*\* Generator Group A10 \*\*\*\*\*\*\*\*\*\* Ignition Group \*\*\*\*\* Piston & Connecting Rod Group À3 **B1** \*\*\*\*\* Remote Starting Control Group (Used with Three Wire Start Circuits Only) \*\*\*\*\* Valve and Breather Group A6 \*\*\*\*\* Service Kits & Miscellaneous **B2**





### **GENERAL INFORMATION**


#### INSTRUCTIONS FOR ORDERING REPAIR PARTS

For parts or service, contact the dealer from whom you purchased this equipment or refer to your Nearest Authorized Onan Parts and Service Center.

To avoid errors or delay in filling your parts order, please furnish all information requested.

Always refer to the nameplate on your unit.

1. Always give the MODEL, SPEC NO. and SERIAL NO.



- 2. Do not order by reference number; always use part number and description.
- 3. Give the part number, description and quantity needed of each item. If an older part cannot be identified, return the part prepaid to your dealer or nearest Onan Parts and Service Center. Print your name and address plainly on the package. Write a letter to the same address stating the reason for returning the part.
- 4. State definite shipping instructions. Any claim for loss or damage to your unit in transit should be filed promptly against the transportation company making the delivery. Shipments are complete unless the packing list indicates items are back ordered.

Prices are purposely omitted from this Parts Manual due to the confusion resulting from fluctuating costs, import duties, sales taxes, exchange rates, etc.

For current parts prices, consult your Onan Dealer, Distributor or Parts and Service Center.

"En esta lista de partes los precios se omiten de proposito, ya que bastante confusion resulto de fluctuaciones de los precios, derechos aduanales, impuestos de venta, cambios extrajeros, etc."

Consiga los precios vigentes de su distribuídor de productos "ONAN."



#### INTRODUCTION

This catalog applies to the standard AJ Recreational Vehicle generator set. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number in the parts list for that group. Parts illustrations are typical. Using the Model and Spec No. from the nameplate, select parts from this catalog that apply to your set. Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left sides are determined by facing the engine end (front) of the set.

#### DATA TABLE

MODEL AND SPEC NO.	TYPE	WATTS	VOLTS	HERTZ	WIRE	PHASE
2.7 AJ-1R/*	Remote	2750	120	<b>6</b> 0	2	1

<sup>\* -</sup> The Specification Letter advances (A to B, B to C, etc.) with manufacturing changes. The letter R in MODEL and SPEC denotes electric start with start-stop at both the set and the remote control.

NOTE: Hertz is a unit of frequency equal to one cycle per second.


#### NOTICE!

ITEMS REFERENCED AS OPTIONAL INDICATE PART IS FACTORY INSTALLED AND MAY NOT BE APPLICABLE TO ALL MODELS. FOR FIELD CONVERSIONS ADDITIONAL PARTS ARE USUALLY REQUIRED.



Generation

### **GEARCASE GROUP**




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	103-0435	1	Gearcase, Assembly (Includes	15	103-0013	1	Gasket, Gear Cover
			Parts Marked *)	16	150-1428	1	Link, Governor Arm to
2	516-0117	1	*Pin, Roll (3/16 x 13/16")				Carburetor
			Governor Cup Stop	17	518-0004	1	Clip, Governor Link to
3	150-1426	1	*Arm & Shaft, Governor				Carburetor
4	150-0177	1	*Stud, Governor Sensitivity	18	150-0639	1	Joint, Ball
			Adjusting	19	815-0046	2	*Screw, Machine - Pan Head,
5	150-1187	1	*Yoke, Governor Shaft				Cross Recessed (#8-32 x 3/8")
6	509-0008	1	*Seal, Oil - Governor Shaft	20	SCREW, CAI	P-HEXHE	AD
7	510-0008	1	*Bearing, Governor Shaft -		800-0031	2	5/16-18 x 1-1/2"
•		•	Lower		800-0034	2	5/18-18 x 2-1/4"
8	510-0013	1	Bearing, Governor Shaft - Upper	21	850-0045	4	Washer, Lock - Gear Cover Mounting
9	510-0014	1	*Ball, Governor Shaft Thrust	22	815-0290	1	Screw, Tapping - Hex Washer
10	150-1429	1	Bracket, Governor Spring				Head (1/4-20 x 5/8")
11	509-0012	1	"Seal. Oil	23	870-0053	2	*Nut, Hex (#10-32)
12	150-0098	i	Spring, Governor	24	870-0053	1	Nut, Hex (#10-32)
13	150-0096	1	Stud, Governor Spring				, , , , , , , , , , , , , , , , , , , ,
		•	Tension Adjusting	• •	Included in G	ear Cover	Assembly.
14	870-0131	2	Nut, Hex - with External Tooth Lockwasher (#10-32)				•





### CYLINDER BLOCK GROUP







### CYLINDER BLOCK GROUP

REF.	PART NO.	QTY.	PART DESCRIPTION	REF.	PART NO.	QTY. U <b>SE</b> D	PART DESCRIPTION
1	110-2252	1	Cylinder Block Assembly	24	526-0264	7	Washer, Flat - Hardened
		•	(Includes Parts Marked *)				(11/32" ID x 23/32" OD x 1/6" THK)
2	110-0441	2	'Guide, Valve	25	SCREW, CAI	P-HEXHE	AD (Hardened)
3	INSERT VAL				110-0879	4	Cylinder Heed
•	110-0826	1	*Standard				(5/16-18 x 1-1/4")
	110-0826-02	1	002" Oversize		110-0284	3	Cylinder Head
	110-0826-05	1	.005" Oversize				(5/16-18 x 1-1/2")
	110-0826-10	1	010" Oversize	26	120-0387	1	"Tube, Crankcase (Pressed
	110-0826-25	1	025" Oversize				in Block)
4	101-0257	1	'Gasket Kit, Bearing Plate to Engine	27	505-0274	1	Plug, Öil By-Pass (1/8" × 1/4")
5	330-0079	1	Cover, Access	28	850-0040	2	Washer, Lock - Spring (1/4")
6	101-0367	2	*Beering, Cemehaft	29	508-0148	1	Grommet, Generator Adapter
7	231-0179	1	*Plate, Generator Adapter	30	403-0656	<b>t</b>	Bott, Eye - Lifting
-		•	& Rear Bearing (Less	31	102-0689	2	Stiffener, Oil Pan
			Bearing)	32	526-0127	6	Washer, Flat
8	BEARING C	RANKSH	AFT (Front and Rear)	32	DECPOIE!	U	(13/32" ID x 25/32" OD x 1/8" THK)
-	101-0290	2	*Standard	33	851-0005	æ	•
	101-0290-02	2	.002" Undersize	34	800-0007	5 2	'Washer, Lock - Spring (5,15")
	101-0290-10	ž	.010 Undersize	3-	50U~00U/	~	Screw, Cap - Hex Head
	101-0290-20	2	020" Undersize	35	800-0048	•	(1/4-20 x 1")
	101-0290-30	2	030" Undersize	35	000-00-es	6	Screw, Cap - Hex Head (5/16-18 x 3/8")
9	509-0123	1	Seel Oil - Crankshaft Rear	36	309-0237	î	Switch, Oil Pressure
10	102-0319	i	Pen. Oil	37	403-1067	1	
11	502-0196	1	Elbow, Oil Pressure Switch	38	403-1064		Plate, Mounting
12	102-0018	1	Gasket, Oil Pan	39	850-0050	ā	Bracket, Engine Mounting
13	110-0834	ì	Head. Cylinder	40	402-0369	2	Washer, Lock - Spring (3/8") Strap, Recirainer
14	110-0836	i	Gasket, Cylinder Head	41	402-0388	ź	Mount, Vibration Cushion
15	504-0017	ì	Valve, Drain	42	362-0015	7	Nut. Hex (5/16-18)
16	516-0012	ż	'Pin, Dowel - Gear Cover	43	850-0045	7	Washer, Lock - Spring (5/16")
		_	Alignment	44	526-0041	5	· • • • • • • • • • • • • • • • • • • •
17	800-0029	5	*Screw, Cep - Hex Head (5/16-18 x 1-1/8")			•	Washer, Flat (21/64" ID x 1" OD x 1/16" THK)
18	517-0048	1	*Plug. Expansion Rear Cam	45	134-2723	1	Bracket, Backplate
	• • • • • • •	,	Bearing	46	520-0119	2	Stud, Engine Mounting Bracket
19	120-0012	1	Plunger, Oil By-Pass	47	104-0091	2	Nut, Engine Mounting
20	120-0140	1	Spring, Oil By-Pass Plunger	•••		-	Bracket
21	120-0571	1	Cup. Oil Pump Intake	48	102-0753	Ť	Plug, Oil Fill
	400 000 4		(Includes Screen)	49	102-0612	1	Gasket, Oil Fill Plug
22	120-0394	1	Pump, Oil	50	418-0077	2	Cable, Battery
23	120-0161	1	Gasket Kit, Oil Pump			_	——————————————————————————————————————

<sup>\* -</sup> Included in Cylinder Block Assembly.

#### VALVE AND BREATHER GROUP

MEF.	PART NO.	QTY. U <b>S</b> ED	PART DESCRIPTION		
1	110-0828	1	Valve, Intake		
2	110-0827	1	Valve, Exhaust		, 7
3	110-0609	2	Spring, Valve		li ii
4	110-0558	1	Retainer, Valve Spring - Intake		
5	110-0540	1	Rotocap, Valve - Exhaust	9.1	3 3 8
6	110-0008	4	Lock, Valve Spring Retainer	<u>, ''</u>	
7	115-0006	2	Tappet, Valve		9 8
8	110-2248	1	Cover, Valve	14	4
9	110-0832	1	Gasket, Valve Cover		6
10	123-0486	1	Valve, Breather		A 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
11	503-0702	1	Hose, Breather (18-1/2")		6 8
12	900-0015	1	Screw, Cap - Hex Head (1/4-20 x 3")	12	7 7-7
13	526-0063	1	Washer, Flat - Copper (17/64" ID x 7/16" OD x 1/32" THK)		
14	503-0614	1	Clamp, Breather Hose	13	



### PISTON AND ROD GROUP



REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	PISTON ASSE	EMBLY (	ncludes Pin and Rings)
	112-0127	1	Standard
	112-0127-05	1	005" Oversize
	112-0127-10	1	010" Oversize
	112-0127-20	1	020" Oversize
	112-0127-30	1	030" Oversize
	112-0127-40	1	040" Oversize
2	112-0063	1	Pin. Piston
3	112-0013	2	Ring, Retaining
4	RING SET	-	
	113-0175	1	Standard
	113-0175-10	1	.010" Oversize
	113-0175-20	1	020" Oversize
	113-0175-30	1	030 Oversize
	113-0175-40	1	.040" Oversize
.5	ROD, CONNE	CTING	
_	114-0095	1	Standard
	114-0095-10	1	010" Undersize
	114-0095-20	1	020 Ungersize
	114-0095-30	i	030" Undarsize
6	114-0023	2	Screw, Cap - Hex Heed (Hardened)
7	854-0014	2	Washer, Lock - Internal Tooth (1/4")


### CRANKSHAFT AND CAMSHAFT GROUP

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	11 13 12 5
1	104-0660	1	Crankshaft	
2	104-0050	1	Washer, Crankshaft Goar	
3	518-0012	1	Ring, Lock - Crankshaft Gear Washer	
4	104-0048	1	Gear, Crankshaft	
5	105-0300	1	Camshaft & Pin Assembly	
8	150-1116	1	Cup, Governor	
7	515-0001	1	Key, Woodruff	
8	150-0078	1	Ring, Lock - Cam, Center Pin	
9	105-0004	1	Washer, Camshaft Thrust	
10	510-0015	5	Ball, Fly - Governor	
11	150-0075	1	Pin, Camshaft Center	
12	515-0001	1	Key, Woodruff	
13	105-0377	1	Gear, Camshaft (Includes Flyball, Spacer & Plate)	
14	150-1267	1	Spacer, Flyball	
15	150-0077	1	Piate, Flyball	900





#### **FUEL SYSTEM GROUP**




教誓F. NO.	PART NO.	QTY. USED	PART DESCRIPTION	ref. No.	PART NO.	QTY. USED	PART DESCRIPTION
1	146-0191	1	*Carburetor	22	307-1279	1	Valve, Fuel Solenoid
2	145-0446	3	Gasket, Air Cleaner to	23	502-0433	1	Elbow, Hose
			Carburstor	24	520-0326	ż	Stud (1/4-28 x 1/4-20 x 1-3/32")
3	154-1601	1	Manifold, Intake	25	141-0078	1	Gasket, Carburator Mounting
4	1 <b>49</b> -1353	1	Filter, Fuel	26	526-0063	2	Washer, Flat - Copper
5	149-1352	1	Pump, Fuel	20	520-0903	•	(17/84" ID x 7/16" OD x 1/32" THK)
6	149-0003	1	Gasket, Pump Mounting	27	815-0285	2	Screw, Machine - Round Head
7	501-0001	1	Line, Fuel Pump to Carburetor	<b>4.</b> r	015-0200	•	with External Tooth Lockwasher (#8-32 x 5/16")
8	520-0195	1	Elbow, Pipe	28	526-0048	2	Washer, Flat - Brass
9	145-0454	. 1	Adapter, Air Cleaner to Carburetor			_	(11/64" ID x 3/8" OD x 1/32" THK)
10	502-0082	1	Nipple, Solenoid Mounting	2 <del>9</del>	815-0433	2	Screw, Self-locking -
11	140-1287	1	Plate, Air Cleaner Base				Fillister Head
12	140-1288	1	Cover, Air Cleaner				(1/4-20 x 5/8")
13	140-1188	1	Element, Air Cleaner	30	812-0085	2	Screw, Machine - Round
14	503-0731	1	Clamp, Hose				Head (#6-32 x 1-1/8")
15	502-0020	1	Elbow, Pipe - Street	31	850-0025	4	Washer, Lock - Spring (#8)
	<b>001 001</b>		(1/8 NPT)	32	815-0190	2	Screw, Tapping - Round
16	115-0025	2	Nut, Hex (1/4-28) - Hardened				Head (#8-32 x 3/8")
17	850-0040	4	Washer, Lock - Spring (1/4")	33	153-0420	1	Adapter, Electric Choke
18	520-0195	1	Stud (1/4-20 x 2-3/16")	34	153-0440	1	Bracket, Electric Choke
19	865-0020	1	Nut, Wing (1/4-20)	35	153-0017	1	Element, Choke Bime at
20	800-0012	1	Screw, Cap - Hex Head (1/4-20 x 2-1/4")	36	153-0115	1	Cover Assembly, Choke (32 Volt Element)
21	800-0007	1	Screw, Cap - Hex Head (1/4-20 × 1")	37	501-0005	1	Line, Fuel
			(1/7°4V n + /			_	

<sup>\* -</sup> See Separate group for component parts.





### **CARBURETOR PARTS GROUP**





REF. NO.		QTY. USED	PART DESCRIPTION	REF NO		QTY. U <b>S</b> ED	PART DESCRIPTION
	146-0191	1	Carburetor, Gasoline	11	146-0116	1	*Needle, idle
	146-0149	•	Repair Kit, Carburstor	12	146-0107	1	Shaft Assembly, Choke
	140-0149	,	(Includes Parts Marked *)	13	146-0104	1	Valve, Choke
	146-0122	•	Screw, Throttle Stop	14	146-0102	1	Needle Assembly, High Speed
1		1	- · · · · · · · · · · · · · · · · · · ·	15	146-0121	2	Spring, Throttle Stop Screw
2	146-0119	1	Valve, Throttle		THUVIE	-	and idle
3	146-0124	1	*Gaskat Kit, Carburator			_	
4	146-0118	1	Bowl, Fuel	16	146-0120	1	Seal, "O" Ring - High Speed
5	146-0196	1	Shaft Assembly, Throttle				Needle
ě	146-0145	1	*Figat Valve, Seat and	18	146-0117	7	Spring, High Speed Needle
0	170-0175	•	Gasket Package	19	146-0142	1	Screw Assembly & Washer -
7	146-0113	1	Nozzie				Splash Baffle Mounting
8	146-0111	1	*Shaft, Float	20	146-0143	1	Baffle, Splash
9	146-0110	1	Float Assembly				
40	146-0100	9	Screw and Washer	* - 1	nctuded in Rei	pair Kit.	





REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	149-0693	1	Pump, Fuel (Illustrated in Fuel System Group)
	149-0526	1	Repair Parts Kit (Includes Parts Marked *)
1		1	Body, Not Sold Separately
2	815-0148	4	Screw, Machine - Hex Head, Slotted (#8-32 x 7/8")
3	815-0147	2	Screw, Tapping - Oval Head, Cross Recessed (#6-32 × 5/8")
4	149-0096	2	*Valve and Cage
5	149-0095	2	*Gasket, Valve
6	149-0582	1	*Diaphragm Assembly
7	149-0672	1	*Spring
8	149-0539	1	Retainer, Valve Cage
9	149-0675	1	*Spring
10	516-0113	1	Pin, Rocker Arm
11		1	Body, Not Sold Separately

Link and Arm, Rocker

(Sold Only as a Set)

\*Gasket, Pump Mounting \*Gasket, Diaphragm - Lower

Side

\* - Included in Repair Kit.


149-0710

149-0003


149-0858

12

13




#### **IGNITION GROUP**





### **EXHAUST SYSTEM GROUP**






REF. NO.	PART NO.	GTY.	PART DESCRIPTION
1	156-1255	1	Clamp, Muffler (1-1/8" Pipe)
2	155-1256	1	Clamp, Muffler (1-1/4" Pipe)
3	155-1234	2	Bracket, Hanger - Mulfier
4	MUFFLER, E	XHAUST	
	156-1242	1	Spec A Through N
	155-1222	1	Begin Spec N
5	155-1254	1	Spark Arrester (Optional)
6	155-1236	1	Tube, Exhaust
7	TUBE, EXHA	UST	
	155-1318	1	Spec A Through N
	156-1469	1	Begin Spec N
8	505-0779	1	Nipple, Pipe






### AIR HOUSING GROUP



MEF. NO.	PART NO.	OTY.	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	821-0009	4	Screw, Self-locking - Hex Washer Head (1/4-20 x 3/8")	9 10	515-0113 815-0290	1	Kay, Woodruff Screw, Tapping - Hex Washer
2	134-2726	1	Scroll, Air				Head (1/4-20 x 5/8")
3	821-0010	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 1/2")	11	821-0009	3	Screw, Self-locking - Hex Washer Head
4	134-2777	1	Wheel, Blower			_	(1/4-20 x 3/8")
5	104-0690	1	Screw, Cap - Hex Head	12	134-2706	1	Housing and Scroll, Blower
6	850-0056	•	Washer, Lock - Spring (7/16")	13	621-0010	2	Screw, Self-locking - Hex
7	526-0017	7	Washer, Flat - Bress (15/32" IDx 1-1/4" ODx 1/4" THK)				Washer Head (1/4-20 x 1/2")
8	134-1913	1	Hub	14	134-2697	1	Shroud, Cylinder Air
				15	134-2696	1	Cover, Engine Side




### **GENERATOR GROUP**





NEF.	PART	QTY.	PART	NEF		QTY.	PART
NO.	NO.	UGED	DESCRIPTION	***	MO.	UGED	DESCRIPTION
1	234-0497	1	Cover, End Bell	18	516-0103	2	Pin, Ros
2	<del>670 02</del> 72	1	Nut. Socket Drive (3/9-16)	19	520-0351	2	Stud (5/16-18 x 5-1/4")
3	510-0047	1	Georing, Balt	20	520-0831	1	Stud (3/8-16 x 11-43/64")
4	232-0506	1	Clip, Retaining - Bearing	21	882-1015	2	Nut. Hox (5/16-18)
5	CAP, BRUS	H HOLDER		22	856-1006	7	Washer, Lock - External/
	212-1219	2	DC Bruth				internal Tooth (5/16")
	212-1217	4	AC Brush	23	<b>850-0045</b>	7	Washer, Lock - Spring (5/18")
6	BRUSH			24	526-0115	1	Washer Fiat
	214-0100	2	DC		0.00		(11/32" ID x 11/16" OD x 1/16" THK)
	214-0092	4	AC	25	520-1703	1	Stud (5/16-18 x 2-1/8")
7	MOLDER, B	RUSH		26	210-0411	1	Frame, Machined & Drilled -
	212-1218	2	DC Brush				Less Coits & Poleshoes
	212-1216	4	AC Brush	27	862-0015	4	Nut. Hex (5/16-18)
	<b>862-1015</b>	2	Nut. Hex (5/16-18)	26	850-0046	4	Washer, Lock - Spring (5/16")
•	<b>860-0046</b>	3	Wiseher, Lock - Spring (5/16")	29	526-0041	4	Washer, Flat
10	<b>928-0115</b>	2	Washer, Flat	~~	520 00-11	-	(21/64" ID x 1" OD x 1/16" THK)
44	044 0450	_	(11/32" ID = 11/16" OD = 1/16" THK)	29	526-0041	4	Washer, Flat (5/16")
1† 12	211-0173	7	End Bell, Generator	30	402-0389	2	Strap, Restrainer
12	201-2293	7	Armsture Assembly, Includes	31	402-0366	2	Mount, Vibration
13	209-0148	_	Bearing	32	403-1065	ī	Bracket, Mounting - Generator
14	204-0009	1	Commutator (DC)	33	600-0003	1	Screw, Cap - Hex Head
15	800-0063	Ī	Collector Ring (AC)				(1/4-20 x 1/2")
13	WW-W63	4	Screw, Cap - Hex Head	34	856-0006	3	Washer, Lock - External/
16	221-0156	•	(3/8-16 x 1-3/4")	•			internal Tooth (1/4)
17		5	Shoe, Pole	35	962-0001	1	Nut. Hex (1/4-20)
*r	222-1728	7	Colf Assembly, Field (2 Colfs Wired Together)	36	337-0094	1	Strap, Ground



### **CONTROL GROUP**








REF. NO.	PART NO.	GTY. USED	PART DESCRIPTION	REF. NO.		QTY. USED	PART DESCRIPTION
1	812-0152	1	Screw, Machine - Round Head (1/4-20 x 3")	14	856-0003	1	Washer, Lock - External/
2	<b>862-000</b> 1	2	Nut. Hex (1/4-20)		T44 444-		Internal Tooth (#10)
3	<b>853-00</b> 13	2	Washer, Lock - External/	15	508-0026	1	Grommet (13/32")
	304-0006	_	Internal Tooth (1/2")	16	815-0391	2	Screw, Tapping - Hex Head (#10-32 x 1/2")
7		Z	Washer, Centering	17	853-0008	2	Weeken Land. E to all
5	353-0049	7	Resistor, Wirewound (10-Ohm, 45 Watt)			2	Washer, Lock - Éxternal/ Internal Tooth (5/16")
6	815-0261	2	Screw, Tapping - Hex Washer	18	308-0345	1	Switch, Toggle
_		•	Head (1/4-20 x 7/16")	19	812-0076	1	Screw, Machine - Round
7	191-1051	1	Bracket, Solenoid	~~			Head (#8-32 x 5/16")
8	307-0845	1	Relay, Sciencid - Start	20	860-0008	7	Nut, Hex (#8-32)
9	330-0004	1	Cover, Receptacle Box	21	853-0005	1	Washer, Lock - External/
10	813-0096	1	Screw, Machine - Round				Internal Tooth (#8)
		<u>-</u>	Head (#10-32 x 1/4")	22	357-0022	1	Rectifier, Diode
11	856-0003	1	Washer, Lock - External/	23	332-1650	1	Strip, Terminal
- •		•	Internal Tooth (410)	24	332-1646	2	Clip. Retaining
12	312-0058	•	Internal Tooth (#10)	25	338-0745	1	Harness, Wiring
13	813-0096		Capacitor	26	508-0002	ý	Grommet (1/2")
1-39	013-0090	T	Screw, Machine - Round Head (#10-32 x 1/4")	_	301-3680	i	Box, Control



### **REMOTE START CONTROL GROUP - OPTIONAL**

(Used With Three Wire Start Circuits Only.)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	308-0165	1	Control Package - Remote Starting (Includes Parts Marked *)	12	300-0986	1	**Control Assembly Remote Starting - Deluxe (Includes Parts Marked £)
2	815-0385	2	*Screw, Machine - Round Head, Black Zinc Finish	13	308-0341	1	£Switch, Push - DPDT (Momentary) With Intergal 12 Volt Lamp)
_			(#6-32 x 1/2")	14	359-0034	1	£Diode
3	308-0154	1	*Switch, Toggle - SPDT	15	302-0888	1	£Meter, Battery Condition
4	308-0168	1	*Plate, Mounting	16	815-0385	2	£Screw, Machine - Round Head,
5	300-1030	1	Control Package - Standard, Remote Starting (Includes Parts Marked †)	47	000 0000	•	Black Zinc Finish (#6-32 x 1/2")
6	815-0380	2	†Screw, Wood - Oval Head,	17	860-0005	2	£Nut, Hex (#6-32)
•	010-0000	_		18	302-0885	1	£Meter, Time Totalizing
7	300-0985	4	Black Oxide (#5 x 1/2")	19	301-3606	1	£Panel, Control
,	300-0903		†Control Assembly, Remote Starting	20	302-0562	1	Voltmeter, DC (0-20)
			- Standard (Includes Parts Marked ★)	21	302-0561	1	Ammeter, DC (0-10)
8	308-0341	1	*Switch, Push - DPDT (Momentary) With Intergal 12 Volt Lamp				l Package 308-0165. I Package 300-1030.
9	301-3566	1	*Panel, Control				
10	300-1031	i	Control Package - Deluxe, Remote Starting (Includes Parts Marked **)	** - Pa	arts Included	in Contro	I Assembly 300-0985 I Package 300-1031. I Assembly 300-0986.
11	815-0380	4	**Screw, Wood - Oval Head, Black Oxide (#5 x 1/2")	~ / .		5511110	A Additiony dour-doub.





#### SERVICE KITS & MISCELLANEOUS

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	(98-1100	1	Decal Kit
	168-0129	1	Gasket Kit, Set
	522-0274	1	Overhaul Kit, Set
	TOUCH-UP	PAINT (Pri	essurized Can)
	525-0137	1	Metallic Green (16 oz.)
	525-0305	1	Non-Metallic Green (13 oz.)

 $\textbf{NOTE:} \ \ \textbf{For other kits, refer to the group for the part in question}.$ 




#### 924-1021 (4-77)

#### SUPPLEMENTARY PARTS LIST


These parts apply to the 2.7AJ Recreational Vehicle Generator Sets begin Serial Number C770217418 during Spec N. Use these parts in place of/or in addition to those listed in the main parts catalog number 924-0220.

#### CYLINDER BLOCK GROUP



PART	QTY	PART
NO.	USED	DESCRIPTION
403-1293	÷ <b>1</b>	Plate, Mounting
403-1294	1	Bracket, Engine Mounting
DELETE		
402-0421	4	Mount, Vibration Cushion
870-0117	2	Nut, Hex - Self Locking (7/16-14)
DELETE	•	(· / # //
DELETE		
DELETE		
403-1288	1	Pan, Drip
800-0076	2	Screw, Cap - Hex Head (7/16-14 x 2-1/4")
	NO.  403-1293 403-1294 DELETE 402-0421 870-0117 DELETE DELETE DELETE 403-1288	NO. USED  403-1293 1 403-1294 1 DELETE 402-0421 4 870-0117 2  DELETE DELETE DELETE DELETE 403-1288 1





REF.	PART NO.	QTY. USED	PART DESCRIPTION
9	856-0008	2	Washer, Lock - EIT (5/16")
10	DELETE	•	V . II G 76 T 11 (0/1/ 14)
27	870-0117	2	Nut, Hex - Self Locking (7/16-14)
28	DELETE		
29	DELETE		•
30	DELETE	*	
31	402-0421	2	Mount, Vibration Cushion
37	800-0076	2	Screw, Cap - Hex Head (7/16-14 x 2-1/4")
38	850-0050	2	Washer, Lock - Spring (3/8")
39	800-0050	2	Screw, Cap - Hex Head (3/8-16 x 1")

924-0220

12020K

FOR STANDARD PARTS REFER TO CATALOG\_\_\_

KEY NO. \_\_\_\_

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. \_

611-1106-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
				T	
503-0679	1	Hose, Breather (13" LG)			
505-0906	1	Nipple, Exhaust (3/4" x 5" LG)			
141-0078	2	Gasket - (1) Carburetor Mtg. (1) Intake Manifold Mtg.			
149-1460	1	Line, Fuel - Filter to Carburetor)		•	
149-1549	1	Shield, Fuel Deflection			
502-0002	1	Elbow, Inverted Male - Carb Inlet			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve			
332-0527	1	Terminal, Solenoid Lead (Positive Coil Post)			
166-0286	1	Screw, Ignition Coil Bracket			
332-0050	1	Clip, Wire - Spark Plug Lead	•		
332-1918	1	Strip, Terminal			
508-0005	1	Grommet, Rubber - Control Box (9/16" Hole)			·

2.0AJ-52R

FOR STANDARD PARTS REFER TO CATALOG 924-0220

\_ KEY NO.-\_\_

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. \_\_\_\_

611-1106-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
503-0679	1	Hose, Breather (13" LG)			
505-0906	1	Nipple, Exhaust (3/4" x 5" LG)			
141-0078	2	Gasket - (1) Carburetor Mtg. (1) Intake Manifold Mtg.			
149-1460	1	Line, Fuel - Filter to Carburetor		•	
149-1549	1	Shield, Fuel Deflection			
502-0002	1	Elbow, Inverted Male - Carb Inlet			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve			
332-0527	1	Terminal, Solenoid Lead (Positive Coil Post)			
166-0286	1	Screw, Ignition Coil Bracket			
332-0050	1	Clip, Wire - Spark Plug Lead			
353-0017	1	Resistor, Fixed (7.5 Ohm, 50 Watt)			
520-0086	1	Stud, Resistor Mounting			
304-0015	2	Washer, Resistor Centering			. The state of the
332-1918	1	Strip, Terminal			
508-0005	1	Grommet, Rubber - Control Box (9/16" Hole)			
201-2318	1	Armature Assembly			·
222-1807	1	Coil Assembly, Field			



Revised.

1 Pagestribution or public of this documer by any means, is strictly prohibited.

12020M

FOR STANDARD PARTS REFER TO CATALOG 924-0220

\_ KEY NO. \_\_-

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. \_

611-1106-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
				1	
503-0679	1	Hose, Breather (13" LG)			
505-0906	1	Nipple, Exhaust (3/4" x 5" LG)			
141-0078	2	Gasket - (1) Carburetor Mtg. (1) Intake Manifold Mtg.			
149-1460	1	Line, Fuel - Filter to Carburetor			
149-1549	1	Shield, Fuel Deflection			
502-0002	1	Elbow, Inverted Male - Carb Inlet			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve			
332-0527	1	Terminal, Solenoid Lead (Positive Coil Post)			
166-0286	1	Screw, Ignition Coil Bracket			
332-0050	1	Clip, Wire - Spark Plug Lead	•		
332-1918	1	Strip, Terminal			
508-0005	1	Grommet, Rubber - Control Box (9/16" Hole)		ν	

Page intribution or public of this documer

12020N

FOR STANDARD PARTS REFER TO CATALOG 924-0220

KEY NO. \_\_-

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. \_\_\_\_

611-1106-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
503-0679	1	Hose, Breather (13" LG)			
505-0906	1	Nipple, Exhaust (3/4" x 5" LG)			
141-0078	2	Gasket - (1) Carburetor Mtg. (1) Intake Manifold Mtg.			
149-1460	1	Line, Fuel - Filter to Carburetor			
149-1549	1	Shield, Fuel Deflection			
502-0002	1	Elbow, Inverted Male - Carb Inlet			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve	·		
332-0527	1	Terminal, Solenoid Lead (Positive Coil Post)			
166-0286	1	Screw, Ignition Coil Bracket			
332-0050	1	Clip, Wire - Spark Plug Lead	•		
353-0017	1	Resistor, Fixed (7.5 Ohm, 50 Watt)			
520-0086	1	Stud, Resistor Mounting			
304-0015	2	Washer, Resistor Centering			
332-1918	1	Strip, Terminal			
508-0005	1	Grommet, Rubber - Control Box (9/16" Hole)			
201-2318	1	Armature Assembly			•
222-1807	1	Coil Assembly, Field			

PECIAL	PARTSI	IST FOR MODEL	2.7AJ-1R
CECHAI	- AHIOI	is fun Milligi	

12020N \_\_ SPEC \_

FOR STANDARD PARTS REFER TO CATALOG 924-0220 KEY NO. \_-

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1106-01

PART NO.	QTY	. DESCRIPTION	PART NO.	QTY.	DESCRIPTION	
				1		ı
503-0679	1	Hose, Breather (13" LG)				
505-0906	1	Nipple, Exhaust (3/4" x 5 "LG)				
141-0078	2	Gasket - (1) Carburetor Mtg. (1) Intake Manifold Mtg.				
149-1460	1	Line, Fuel - Filter to Carburetor				
149-1549	1	Shield, Fuel Deflection				
502-0002	1	Elbow, Inverted Male - Carb				
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve				
332-0527	1	Terminal, Solenoid Lead (Positive Coil Post)				
166-0286	1	Screw, Ignition Coil Bracket	•			
332-0050	1	Clip, Wire - Spark Plug Lead		•		
332-1918	1	Strip, Terminal				
508-0005	1	Grommet, Rubber - Control Box (9/16" Hole)			÷	
155-1239	1	Clamp, Muffler (1-1/2" Pipe)				